

COMPONENTS	Actions to be taken	FREQUENCY
SEEDING DISCS	<ul style="list-style-type: none"> ◦ Clean ◦ Check for wear (change them if circular grooves of 0.5 mm) 	Before each sowing campaign
FRICTION INSERTS	<ul style="list-style-type: none"> ◦ Clean ◦ Check for wear (change them if you no longer see the wear indicators) 	Before each sowing campaign
SELECTORS + PINS + EJECTORS	<ul style="list-style-type: none"> ◦ Clean ◦ Check for wear (change the selectors if you no longer feel offset on the upper part) ◦ Check that the support pins and the ejector spring are not seized 	Before each sowing campaign
LIDS	<ul style="list-style-type: none"> ◦ Checking for leaks and the locking of the emptying trapdoor 	Before each sowing campaign